
P?
CONNECTOR DB37
Reward Connector:
pin 1: manual reward pushbutton (to ground)
pin 2: reward pulse
pin 3: ground
pin 4: inverted reward pulse
pin 9: ground
P?
reward connector
J?
Rear panel connector
J? BNC
Spike 0
Spike 7
Rear Panel Connections
S?
reward
R? 100K
Reward Duration
+5v
LED 0
D? LED 0
R? 1.3K
D? LED 1
D? LED 2
D? LED 3
D? LED 4
D? LED 5
D? LED 6
D? LED 7
J?
Front panel connector
S?
Reward lock
(flush)
R? 4.7K
Front Panel Connections
Title
Example use of Spike Board
Size
A
Document Number
{Doc}
Rev
0.1
Date:
Friday, October 02, 1998
Sheet 1 of 1